


How to change the LAN IP of the extender?

It is suitable for : **EX150, EX300**

1-1. Please login the extender's web-setting interface. (Default IP address: 192.168.1.254, User name: admin, Password: admin)



1-2. Click Advanced Setup->System->LAN/DHCP Server



1-3. Change the LAN IP accordingly.

